

## E-RA E-Curre Jaw RA Curre Jaw

## Adequate for measurement at a deep location of sac hole



With "Curre jaw", this caliper is adequate for measurement of work for which straight jaws cannot be used.





## ■ RA: Specifications

| U | ni | t : | m | m) | ) |
|---|----|-----|---|----|---|
|---|----|-----|---|----|---|

| Model | Measuring<br>length | Minimum reading                            | Maximum per | missible error<br>SMPE | Weight | А   | В  | С  | D    | Е   | F  | G  | Н   | ı  | J | К  | L | М | N  |
|-------|---------------------|--|-------------|------------------------|--------|-----|----|----|------|-----|----|----|-----|----|---|----|---|---|----|
| RA15  | 150                 | O.O5 Division of 19 mm into 20 equal parts | ± 0.10      | ± 0.10                 | 170g   | 238 | 90 | 14 | 20 ( | 8.5 | 12 | 29 | 5.5 | 36 | 4 | 16 | 8 | 3 | 20 |
| RA20  | 200                 |  |             |                        | 200g   | 290 |    | 14 | 30   | 8.5 |    |    |     |    |   |    |   |   |    |